

Istruzioni di montaggio ed uso
Operation Instructions
Instructions de montage et usage
Montage- und Bedienungsanleitung
Instrukcijas de montāžai un lieto
Instrucțiuni pentru montare și utilizare

IRSAP
creating your comfort


IRSAP SPA
45031 Arquà Polesine (RO) Italy
Tel. +39 0425 466611 - Fax +39 0425 466662
Website: <http://www.irsap.com>
E-mail: info@irsap.it

IR GROUPE SARL
19, Chemin de la Plaine 69390 Vourles (France)
Tel. +33 04 28 00 01 67 - Fax +33 04 72 31 86 40
Web: <http://www.irsap.com>
E-mail: info@irsap.fr

IRSAP-RIHOSS Clima Integrat S.R.L.
Oficina y Almacén P.I. CAMÍ RAI
Leonardo da Vinci 4 08850 Gavà (Barcelona)
Tel. 93 633 47 00 - Fax 93 633 47 04
E-mail: www.informacion@irsap.com
www.irsap.com

IRROM Industrie S.R.L.
Str. Principale 1/A, Sat Fundătura, Icoi 407336,
Jud. Cluj, România
Tel: +40 (0)264 263400 - Fax: +40 (0)264 263404
Web: www.irsap.ro

Accessori non inclusi-Accessories not compris
Accessories not included-Zubehör nicht inklusive
Accessories no incluidos-Accessories incluídas



Accessori inclusi-Accessories compris
Accessories included-Zubehör inklusive
Accessories incluidos-Accessories incluídas

